

# CAMPUS RACK



## Orderly Bike Parking

The design of this bike rack supports the frame of the bike while keeping the fork from twisting. The result is convenient, orderly bike parking. The Campus Rack is available in single or double sided models in various lengths. The single sided model is ideal for sidewalk placement, while the double sided model staggers bikes opposite from each other for greater space efficiency. The Campus Rack will also accommodate scooters.

PRODUCT & PRICING INFO CONTACT


 **STREETSCAPES**  
STREETSCAPES.BIZ

Info@streetscapefurniture.com ■ 303.398.7040

# CAMPUS RACK

## Just your size.

The Campus Rack is available in a variety of configurations to meet your bike parking capacity needs.



### FINISH OPTIONS

Galvanized




Stainless



### MOUNT OPTIONS

Surface



In-Ground



### Powder Coat

White	Black	Light Gray RAL 7042	Deep Red RAL 3003	Yellow RAL 1023
CNH Bright Yellow	Orange RAL 2004	Blue RAL 5005	Sky Blue RAL 5015	Hunter Green RAL 6005
Light Green RAL 6018	Green RAL 6016	Sepia Brown RAL 8014	Bronze	Silver 9007
Dark Purple	Flat Black	Wine Red RAL 3005	Beige RAL 1001	Iron Gray 7011

# CAMPUS RACK

## Submittal Sheet

### CAPACITY


3-11 Bikes

### MATERIALS

Centerbeam: 3" OD 7 gauge tube  
Ears: 1.25" OD 11 gauge tube.  
All welds to be continuous MIG welds



### FINISHES

- ☐ **Galvanized**  
An after fabrication hot dipped galvanized finish is our standard option.
- ☐ **Powder Coat**  
Our powder coat finish assures a high level of adhesion and durability by following these steps:  
1. Sandblast  
2. Epoxy primer electrostatically applied  
3. Final thick TGIC polyester powder coat
- ☐ **Stainless**  
Stainless Steel: 304 grade stainless steel material finished in either a high polished shine or a satin finish.



### MOUNT OPTIONS

- ☐ **In-ground**  
In ground mount is embedded into concrete base. Specify in ground mount for this option.
- ☐ **Surface**  
Foot Mount has 34" x 3" channel feet and can be left freestanding or anchored to the ground.




## CAMPUS RACK


### Setbacks

---

Single Sided



Double Sided



## CAMPUS RACK

# Installation Instructions – Surface Mount

---

### TOOLS NEEDED


Tape Measure  
Marker or Pencil  
Masonry Drill Bit 3/8"  
Drill (Hammer drill recommended)  
Hammer  
Wrench 9/16"

### RECOMMENDED BASE MATERIAL

For freestanding units, nearly any level surface is acceptable and no anchoring is necessary. For anchored units a concrete base is best.


---

1




Place the rack in the desired location. Use a marker or pencil to outline the holes of the flange onto the base material.

2




Drill 3/8" diameter holes 3" deep into surface. Make sure the holes are at least 3" away from any cracks in the base material.

3



Place rack (and washers to level rack if necessary) over holes.

4



Thread nuts onto anchors, leaving approximately 1/4" of the anchor protruding, and tap into surface. Tighten nuts down to secure rack.

## CAMPUS RACK

# Installation Instructions – In Ground Mount

### TOOLS NEEDED


Level  
Cement mixing tub  
Shovel  
Trowel

Hole coring machine with 4" bit  
Access to water hose  
Materials to build brace (see "Install Tip" at bottom of page)


### INSTALLING INTO EXISTING SIDEWALK

Core holes no less than 4" diameter (5" recommended) and 10" deep into sidewalk. Fill holes with Por-Rok or epoxy grout. Place rack into holes, making sure the rack is level. 33"-36" of the rack should remain above the surface. If the rack is less than 33" high, it will not support the bike adequately. Make sure the rack is level and held in place until the grout has set.


### INSTALLING INTO A NEW SIDEWALK




Place corrosion resistant sleeve (min. 4" inside diameter) in sand pour bed in exact location where rack will be installed. Make sure top of sleeve is at same level as desired finished concrete surface. Fill sleeve with sand to keep it in place and prevent it from filling with concrete.



After appropriate cure time, dig out sand from sleeves and insert racks, making sure they are level and at the appropriate height. Pour in Por-Rok or epoxy grout and allow to set.



Pour concrete and allow to cure.



#### INSTALL TIP

An easy way to brace the rack while the grout sets is to bolt two 1x4" boards together at one end and clamp them onto the rack like a clothes pin.