

HI ROLLER



Support Your Bikes

The Hi Roller puts a unique twist on a familiar design. By adding an extra bend to a rolling-style rack, the Hi Roller provides a much greater degree of bicycle support than its purely vertical counterpart. The Hi Roller can be ordered for in-ground or foot mounted installation. This rack uses thick pipe construction and allows for one of the wheels and frame to be secured using a u-style bike lock. The Hi Roller is available in various lengths to meet your bike capacity needs.

PRODUCT & PRICING INFO CONTACT

 **STREETSCAPES**
STREETSCAPES.BIZ

Info@streetscapefurniture.com ■ 303.398.7040

HI ROLLER

Just your size.



The Hi Roller is available in 4 lengths to meet your bike parking capacity needs.

Hi2H
42"
4 Bikes

Hi3H
66"
5 Bikes

Hi4H
90"
6 Bikes

Hi5H
114"
7 Bikes



FINISH OPTIONS

Galvanized



Stainless




Powder Coat

| | | | | |
|-------------------------|--------------------|-------------------------|----------------------|--------------------------|
| White | Black | Light Gray RAL 7042 | Deep Red RAL 3003 | Yellow RAL 1023 |
| CNH Bright Yellow | Orange RAL 2004 | Blue RAL 5005 | Sky Blue RAL 5015 | Hunter Green RAL 6005 |
| Light Green RAL 6018 | Green RAL 6016 | Sepia Brown RAL 8014 | Bronze | Silver 9007 |
| Dark Purple | Flat Black | Wine Red RAL 3005 | Beige RAL 1001 | Iron Gray 7011 |

HI ROLLER

Submittal Sheet



- CAPACITY

Hi2H: 4 Bikes

Hi3H: 5 Bikes

Hi4H: 6 Bikes

Hi5H: 7 Bikes
- MATERIALS

2.375" OD Schedule 40 Steel Pipe
- FINISHES

☐

Galvanized

An after fabrication hot dipped galvanized finish is our standard option.

☐

Powder Coat

Our powder coat finish assures a high level of adhesion and durability by following these steps:

1. Sandblast

2. Epoxy primer electrostatically applied

3. Final thick TGIC polyester powder coat

☐

Stainless

Stainless Steel: 304 grade stainless steel material finished in either a high polished shine or a satin finish.
- MOUNT OPTIONS

☐



In-ground

In ground mount is embedded into concrete base. Specify in ground mount for this option.


☐

Surface

Foot Mount has two 5"x6"x.25" feet with four anchors per foot. Specify foot mount for this option.



HI ROLLER Setbacks



HI ROLLER

Installation Instructions – Surface Mount


TOOLS NEEDED

Tape Measure
Marker or Pencil
Masonry Drill Bit 3/8"
Drill (Hammer drill recommended)
Hammer
Wrench 9/16"
Level

RECOMMENDED BASE MATERIAL


Solid concrete is the best base material for installation. To ensure the proper anchors are shipped with your rack, ask your Dero Rack representative which anchor is appropriate for your application. Be sure nothing is underneath the base material that could be damaged by drilling.

1




Place the rack in the desired location. Use a marker or pencil to outline the holes of the flange onto the base material.

2




Drill 3/8" diameter holes 3" deep into surface. Make sure the holes are at least 3" away from any cracks in the base material.

3



Place rack (and washers to level rack if necessary) over holes.

4



Thread nuts onto anchors, leaving approximately 1/4" of the anchor protruding, and tap into surface. Tighten nuts down to secure rack.

HI ROLLER

Installation Instructions – In Ground Mount

TOOLS NEEDED


Level
Cement mixing tub
Shovel
Trowel

Hole coring machine with 4" bit
Access to water hose
Materials to build brace (see "Install Tip" at bottom of page)


INSTALLING INTO EXISTING SIDEWALK

Core holes no less than 4" diameter (5" recommended) and 10" deep into sidewalk. Fill holes with Por-Rok or epoxy grout. Place rack into holes, making sure the rack is level. 33"-36" of the rack should remain above the surface. If the rack is less than 33" high, it will not support the bike adequately. Make sure the rack is level and held in place until the grout has set.


INSTALLING INTO A NEW SIDEWALK



Place corrosion resistant sleeve (min. 4" inside diameter) in sand pour bed in exact location where rack will be installed. Make sure top of sleeve is at same level as desired finished concrete surface. Fill sleeve with sand to keep it in place and prevent it from filling with concrete.



After appropriate cure time, dig out sand from sleeves and insert racks, making sure they are level and at the appropriate height. Pour in Por-Rok or epoxy grout and allow to set.



Pour concrete and allow to cure.

