

TYPE RIDER® RACKS



EXPRESS YOURSELF

Bike parking makes a statement. The line of Type Rider® racks offers customers the chance to have fun with letters and symbols. These laser cut, hand-welded bike racks can be arranged to spell out a word, brand name, and even hashtag. Each letter parks two bikes.

PRODUCT & PRICING INFO CONTACT

 **STREETSCAPES**
STREETSCAPES.BIZ

Info@streetscapefurniture.com ■ 303.398.7040

TYPE RIDER® RACKS



FINISH OPTIONS

Galvanized




Powder Coat

White	Black	Light Gray RAL 7042	Deep Red RAL 3003	Yellow RAL 1023
CNH Bright Yellow	Orange RAL 2004	Blue RAL 5005	Sky Blue RAL 5015	Hunter Green RAL 6005
Light Green RAL 6018	Green RAL 6016	Sepia Brown RAL 8014	Bronze	Silver 9007
Dark Purple	Flat Black	Wine Red RAL 3005	Beige RAL 1001	Iron Gray 7011

TYPE RIDER® RACKS

Submittal Sheet



Widths vary by letter

CAPACITY 2 bikes

MATERIALS Laser cut 5/8" steel plate hand-welded to 5/8" steel base.

FINISHES

- Powder Coat**
Our powder coat finish assures a high level of adhesion and durability by following these steps:
 1. Sandblast
 2. Epoxy primer electrostatically applied
 3. Final thick TGIC polyester powder coat


- Galvanized**
An after fabrication hot-dipped galvanized finish is our standard option.

MOUNT OPTIONS

Surface
Each Type Rider® Rack has a 5/8" steel base plate with four anchor holes for 3/8" bolts.

TYPE RIDER® RACKS

Setbacks



TYPE RIDER® RACK

Installation Instructions


TOOLS NEEDED

Tape Measure
Marker or Pencil
Masonry Drill Bit
Drill (Hammer drill recommended)
Hammer
Wrench 9/16"
Level

RECOMMENDED BASE MATERIAL


Solid concrete is the best base material for installation. To ensure the proper anchors are shipped with your rack, ask your Dero Rack representative which anchor is appropriate for your application. Be sure nothing is underneath the base material that could be damaged by drilling.

1




Place the rack in the desired location. Use a marker or pencil to outline the holes of the flange onto the base material.

2




Drill 3/8" diameter holes 3" deep into surface. Make sure the holes are at least 3" away from any cracks in the base material.

3



Place rack (and washers to level rack if necessary) over holes.

4



Thread nuts onto anchors, leaving approximately 1/4" of the anchor protruding, and tap into surface. Tighten nuts down to secure rack.