

# SADDLE BUDDY™



## Saddle Up.

Designed for trailheads, bike parks and picnic areas, the Saddle Buddy™ offers a resting place for cyclists' noble steeds. The convenient bar allows cyclists to keep their bikes upright while taking a break or gearing up for the ride ahead. This is not designed to be a lockable bike rack, but rather a convenience for riders who won't be leaving their bikes unattended.

PRODUCT & PRICING INFO CONTACT


 **STREETSCAPES**  
STREETSCAPES.BIZ

Info@streetscapefurniture.com ■ 303.398.7040

# SADDLE BUDDY™

## EASY ASSEMBLY

The Saddle Buddy™ is easy to install




## FINISH OPTIONS

Galvanized



## MOUNT OPTIONS


Surface



In-Ground




Rail



# SADDLE BUDDY™

## Submittal Sheet

---



### MATERIALS

Horizontal Assembly: 1.5" Sch. 40 Pipe  
Vertical Assembly: 2" Sch. 40 Pipe

### FINISHES

☐

#### Galvanized

An after fabrication hot dipped galvanized finish is our standard option.

### MOUNT OPTIONS

☐

#### In-ground

In ground mount is embedded into concrete base. Specify in ground mount for this option.

☐


#### Surface

Foot Mount has two 6" circular feet with three anchors per foot. Specify foot mount for this option.

**SADDLE BUDDY™**

## Setbacks

---






# Installation Instructions - Assembly

---


## TOOLS NEEDED

Hex key


---



Align the horizontal cross bar and vertical members so the bolt holes line up.



Ensure the countersunk side of the vertical members is facing out and insert the countersunk hex bolts through the vertical member, threading into the brass colored, threaded riv-nut fixed into the horizontal cross bar.



Tighten the countersunk bolts with the appropriate hex key until the countersunk head seats in the countersunk hole on the vertical member, and so there is no play between the bolted components.

# Installation Instructions – Surface Mount

---


## TOOLS NEEDED

Tape Measure  
Hammer  
Electric Hammer Drill  
3/8" x 6" Masonry Drill Bit  
Hex Key


## RECOMMENDED BASE MATERIAL

Solid concrete is the best base material for installation. To ensure the proper anchors are shipped with your rack, ask your Dero Rack representative which anchor is appropriate for your application. Be sure nothing is underneath the base material that could be damaged by drilling.


---

**1**


Place the rack in the desired location. Use a marker or pencil to outline the holes of the flange onto the base material.

**2**

Drill 3/8" diameter holes 3" deep into surface. Make sure the holes are at least 3" away from any cracks in the base material.

**3**

Place rack (and washers to level rack if necessary) over holes.

**4**

Thread nuts onto anchors, leaving approximately 1/4" of the anchor protruding, and tap into surface. Tighten nuts down to secure rack.

# Installation Instructions – In Ground Mount

---

## TOOLS NEEDED

Level  
Cement mixing tub  
Shovel  
Trowel

Hole coring machine with 4" bit  
Access to water hose  
Materials to build brace (see "Install Tip" at bottom of page)


---

## INSTALLING INTO EXISTING CONCRETE


Core holes no less than 3" diameter and no less than 11" deep into sidewalk. Fill holes with Super Por-Rok or epoxy grout. Place Saddle Buddy™ into holes, making sure the rack is level. The welds at the base should be just below the surface. Make sure the rack is level and held in place until the grout has set.

---


## INSTALLING INTO NEW CONCRETE

**1**

Place corrosion resistant sleeve (min. 4" inside diameter) in sand pour bed in exact location where rack will be installed. Make sure top of sleeve is at same level as desired finished concrete surface. Fill sleeve with sand to keep it in place and prevent it from filling with concrete.

**2**


Pour concrete and allow to cure.

**3**

After appropriate cure time, dig out sand from sleeves and insert racks, making sure they are level and at the appropriate height. Pour in Por-Rok or epoxy grout and allow to set.

### INSTALL TIP

An easy way to brace the Saddle Buddy™ while the grout sets is to bolt two 1x4" boards together at one end and clamp them onto the legs of the Saddle Buddy™ like a clothes pin.



# Installation Instructions – Rail Mount

---

Place 3/8" carriage bolts through Saddle Buddy™ flange and rail as illustrated below. Apply washers and nuts from underside of rail. Use a 9/16" socket to tighten nuts.

